



MIK HD Compatible Carrier Installation Instructions

Step 1.

Fit the upper attachment brackets to the carrier. Leave the bolts loose so the brackets can slide in and out of the carrier.




Step 2.

Bolt the lower legs of the carrier to the dropouts on the frame of the bicycle. Leave the bolts loose so the carrier can rotate about the bolts.



Step 3.

Attach the angled end of the brackets to the mounting points on the seat stays of the bicycle frame.



Step 4.

Now the carrier is attached to the bicycle at all attachment points, adjust the carrier so the carrying surface is level.

Once the desired carrier position has been attained, tighten all bolts to secure the carrier in position.



NOTE: We suggest that you use "Loctite" or any proprietary product which is used to secure threaded bolts and screws, this will help to eliminate loosening due to vibration.